




PURE *sigma*

Connect any spreader to PURE Sigma side plough platform, lift and lock PURE Sigma on the carrier and you are ready for winter roadwork. Take care of snow with PURE Delta⁴ side plough and use spreader for antiskid treatment. Then unlock PURE Sigma, leave it on support legs and you have your truck fast and easily ready for any other use.



PURE Road Maintenance

Tel +358 10 2321 000
www.pajakulma.fi



PAJAKULMA

JYKI GROUP



PURE *sigma*

PURE SIGMA SIDE PLOUGH PLATFORM WITH PURE DELTA4 SIDE PLOUGH



Max working width	3950 mm
Total width of blade	4450 mm
Blade height	1050 mm
Blade weight	700 kg
Ploughing angle	0-60°
Blade angle	60°
Required hydraulic flow	100 L/min / 210 bar
Transportation width of side plough	570 mm

Weight without spreader approx. 2700 kg *

Weight without spreader and side plough blade approx. 1900 kg *

x = depends on hook lift width

* Weights valid for longest possible frame.



PURE Road Maintenance

Tel +358 10 2321 000
www.pajakulma.fi



PAJAKULMA

JYKI GROUP